


WF18 Sash Window Stop Fitting Instructions



1. Ensuring depth is appropriate for ferrule being used, pilot a 9mm diameter hole in the inside face of the outer frame approximately 75mm from the face of the inner frame. This will allow both top and bottom sashes enough room to open for ventilation (to further restrict movement of sashes place ferrule closer to inner frame).
2. Screw ferrule into piloted hole using a flat head screwdriver until completely flush with frame surface
3. Screw stop into ferrule using Allen key provided.